

# HYPERCONVERGENCE SOFTWARE IN 3 EASY STEPS

## Select Your Preferred Server

1


### MINIMUM SERVER CONFIGURATION

Components	Quantity/Description
CPU Make	Intel
CPU Sockets	Min 2
Cores Per CPU	Min 8
CPU Clock Speed	Min 2.2GHz
Memory	48GB for Springpath software
Networking	2x 10GbE
Storage Controller	Must support pass through or JBOD mode
HDD	Min 4 drives, 7200RPM, SAS or SATA
SSD 1	Min 120GB, SATA
SSD 2	Min 400GB, SATA



## Deploy Springpath Data Platform

2




Start with 3 servers or more

Install Springpath software

## Enjoy The Benefits of Springpath Hyperconvergence Software

3



CONTACT US  
[info@springpathinc.com](mailto:info@springpathinc.com)  
 1-877-240-PATH